



PREMIUM PANEL

# CARE & CLEANING GUIDELINES

## CLEANING AGENTS AND DETERGENTS SHOULD NOT CONTAIN:

Aromatic hydrocarbons, ester, ketones, halogenated hydrocarbons or alcohol above 25%, or vinegar-based cleaners.

- **NO SOLVENTS**  
paint thinners, turpentine, isopropyl alcohol, acetone, etc.
- **NO ABRASIVE DETERGENTS**  
baking soda, calcium carbonate, powdered feldspar, etc.
- **NO FURNITURE POLISH DESIGNED FOR WOOD**
- **NO DENATURED ALCOHOLS**  
ethyl alcohol, white spirits, etc.
- **NO CLEANER IN COMBINATION WITH A BRUSH OR SCRUBBING**
- **USE OF BRUSHES AND SCOURING PADS IS NOT SUGGESTED**



## GENERAL CLEANING FOR BOTH HIGH GLOSS & SUPER MATTE FINISHES

A clean cotton or microfiber cloth saturated with a mixture of warm water (99%) and a mild, nonabrasive dish washing soap (1%) can be used to clean MIRLUX by wiping in vertical movements with light pressure.

Never use a dry paper towel for cleaning and do not clean in direct sunlight.

High gloss MIRLUX can be brought to a streak free shine by using Novus 1 plastic protectant or DuPlex Plastic Polish.

## RETAIL CLEANSERS & POLISHES

Test all retail cleaning agents for compatibility with MIRLUX by applying to an inconspicuous area of the cabinet first, to confirm that the cleaner does not damage the surface.

Always read and follow the directions specified on the label and apply with a clean cotton or microfiber cloth, wiping in a vertical motions with light pressure. Mixing agents is not suggested.

